(BASE + OFFSET) == (BASE | OFFSET)

Fig. 1



Fig. 2



Fig. 3



Original Data

FIG. 4A

```
1 Access Address A[i][0]
2 Access Address A[i][1]
3 Access Address B[i][0]
4 Access Address B[i][1]
5 Access Address B[i][2]
6 Access Address B[i][3]
7 Access Address A[i][0]
8 Access Address A[i][1]
```

Pseudo code sequence of accessing A, B, C

FIG. 4B



Data in local memory

FIG. 5A

```
Set the base address to A[i][0]
Access Address A[i][0] (A[i][0]+0)
Set the base address to A[i][1]
Access Address A[i][1] (A[i][1]+0)
Set the base address to B[i][0]
Access Address B[i][0] (B[i][0]+0)
Set the base address to B[i][1]
Access Address B[i][1] (B[i][1]+0)
Set the base address to B[i][2]
Access Address B[i][2] (B[i][2]+0)
Set the base address to B[i][3]
Access Address B[i][3] (B[i][3]+0)
Set the base address to C[i][0]
Access Address C[i][0] (C[i][0]+0)
Set the base address to C[i][1]
Access Address C[i][1] (C[i][1]+0)
```

Pseudo code sequence of accessing A, B, C with initialization code of local memory based address inserted

FIG. 5B



Fig. 6

```
Compute the GEN, KILL, IN, and OUT for each flow node, fill in the hash table {base address, set of offset value pair}
for (each base address in the hash table)
   VAR is the variable accessed by the base address
   for (each offset value pair for this base address)
      int CURR_VAR_ALIGN = current alignment of VAR
      int CURR_BASE_ALIGN = current alignment of the base address
      if (CURR_BASE_ALIGN does not satisfy the condition in Figure 1 for one of the offset value in the pair)
         int NEEDED_BASE_ALIGN  = the minimum base address alignment needed to satisfy the condition in Figure 1 for
      all offset values in the pair
         Int new_align = CURR_VAR_ALIGN * NEEDED_BASE_ALIGN / CURR_BASE_ALIGN
         if (new_align <= MAX_ALIGN(VAR))
            set the alignment of VAR to new_align
            if (the alignment change does not make the base address satisfy the condition in Figure 1 for all offset values in
      the pair)
               restore VAR's alignment to CURR_VAR_ALIGN
            end if
         end if
      end if
```

Fig. 7



Data with adjusted alignment

FIG. 8A

```
Set the base address to A[i][0]
Access Address A[i][0] (A[i][0]+0)
Set the base address to A[i][0]
Access Address A[i][1] (A[i][0]+4)
Set the base address to B[i][0]
Access Address B[i][0] (B[i][0]+0)
Set the base address to B[i][0]
Access Address B[i][1] (B[i][0]+4)
Set the base address to B[i][0]
Access Address B[i][2] (B[i][0]+8)
Set the base address to B[i][0]
Access Address B[i][3] (B[i][0]+12)
Set the base address to C[i][0]
Access Address C[i][0] (C[i][0]+0)
Set the base address to C[i][0]
Access Address C[i][1] (C[i][0]+4)
```

Pseudo code sequence of accessing A, B, C after insert code to initialize the local memory base address

FIG. 8B



Data with adjusted alignment

FIG. 9A

```
Set the base address to A[i][0]
Access Address A[i][0] (A[i][0]+0)
Access Address A[i][1] (A[i][0]+4)
Set the base address to B[i][0]
Access Address B[i][0] (B[i][0]+0)
Access Address B[i][1] (B[i][0]+4)
Access Address B[i][2] (B[i][0]+8)
Access Address B[i][3] (B[i][0]+12)
Set the base address to C[i][0]
Access Address C[i][0] (C[i][0]+0)
Access Address C[i][1] (C[i][0]+4)
```

Pseudo code sequence of accessing A, B, C after insert code to initialize the local memory base address

FIG. 9B


1030
1020
1050
1010
NP
Processor
Local
Memory
Ex.
Memory
Optimizer
1060
1040
1000

Fig. 10


1120
Memory
1110
Processor
1130
Optimizer
1140
Display
1100
Processing Device
1000

Fig. 11


1250
Accessor
1240
Migrator
1230
Third Determiner
1220
Second Determiner
1210
First Determiner
1130

Fig. 12